


Application: Casting AATi SN293/WL/140 Nosing into concrete with Anchor Blocks as per **Fig 1**.

Method

1. Ensure the underside of nosing is clean from dust/dirt or any other contaminants.
2. Cut an appropriate size piece of Damp Proof Course (Rubberoid - Hyload original DPC) to cover the entire internal side of nosing.
3. Apply DPC to cover the entire internal face of the nosing and drill through holes in nosing.
4. Fix by applying clear sealant through fixing holes and then inserting appropriate length M6 stainless steel Pozi countersunk machine screws through nosing and DPC into AATi cast iron Anchor Blocks, tighten to form a secure fixing and wipe away any excess sealant.
5. Position AATi nosing with DPC membrane into mould unit and protect as necessary to stop slurry getting onto visible surfaces of the nosing.
6. Mix and pour concrete.
7. Leave to set.
8. Remove from mould as soon as possible and as necessary.

Fig 1. Sectional view of SN293/WL/140 cast into concrete with Anchor Blocks assembly



NB: Nosing's must be installed in such a way that standing water is omitted. Please refer to AATi O&M Manual
All AATi products are subject to our manufacturing tolerances and should be taken into consideration when installing