



## **AATi Recommended Installation Guideline** **for casting into concrete.**



DATE	15/04/16
REVISION	3

1. Ensure the underside of nosing is clean from dust/dirt or any other contaminants.
2. Cut an appropriate size piece of DPC to cover the entire internal side of nosing.
3. Apply Damp Proof Course (Rubberoid - Hyload original DPC) to cover the entire internal face of the nosing and drill through holes in nosing.
4. Insert M6 x 20 stainless steel countersunk pozi machine screws through nosing and DPC into AATi cast iron anchor blocks and tighten.
5. Position AATi nosing with DPC membrane into mould unit and protect as necessary to stop slurry getting on to visible surfaces of the nosing.
6. Mix and pour concrete.
7. Leave to set.
8. Remove from mould as soon as possible and clean as necessary.

**Fig 1.** Section view of fixing detail



**Fig 2.** Isometric section view of fixing assembly for stair nosing - SN9/55

NB: Nosing's must be installed in such a way that standing water is omitted. Please refer to AATi O&M Manual  
All AATi products are subject to our manufacturing tolerances and should be taken into consideration when installing